


Updating the License Service

Updating your License after a subscription renewal or changing features (ie. Number of licensed seats, or adding the Standard Analysis feature) is now easier if running Version 2.1.0.0 of the License Tools or better.


When the service is running, you can interact using the License Tools, accessible from the icon tray. If the Icon does not appear, run the License Tools V2 from the Structural Toolkit license Tools V2 group.








To see what features you currently have, use the "Dump Feature" and "Show EventLog".



To see is any updates are available to the License, use the "Check for License Updates" and "Show EventLog".

Note: You will require internet connectivity to www.structuraltoolkit.com.au domain.








To apply available updates to the License, use the "Apply License Updates" and "Show EventLog".

Note: If your service has stopped and your subscription is not current, updates will need to be done using the License Updater V2







If you have any questions please call us on 03 9878 4684.

Regards

STK Team

