


Concrete Sleeper Retaining Wall

Rev 0, Created 1 September 2020

A concrete sleeper retaining wall can be designed in Structural Toolkit using two modules – **Sleeper Walls** & **Concrete Member Design**. The following guide will show the step-by-step process of doing this.






Using Sleeper Walls

The first step of designing a concrete sleeper wall is to use the Sleeper Walls module. Upon opening module, fill in the relevant geometry values as shown below. Many of these values will be based on geotechnical recommendations.

Geometry



Next is to fill in any additional design loads specific to the design and the relevant load factors, as seen below. For this design, only the minimum surcharge of 5.0kPa has been added (note for risk class A this would be 2.5kPa).

Design loads - Appendix J & Section 4 - AS4678

Min. surcharge =	5.0	kPa - Table 4.1 Add	itional upright overturning		
Water height (hw) =	0.0	mm (Drained)	Thrust (Va) =	0.00	kN
Surcharge (s) =	5.0	kPa	Overturning (Ma) =	0.00	kNm
			Load factor =	1.50	
Dead only factor =	1.35	(1.35)	Long term LL factor (ΨIo) =	0.40	
Earth factor =	1.25	(1.25)	Va* =	0.00	kN
Live load factor =	1.50	(1.50 - 0.0 for stabilising effect)	Ma* =	0.00	kNm
Stabilising factor =	0.80	AS4678 - Appendix J2	(Thrust/mome	nt applied at t	he top of the wall



Once the geometry and design load values have been set, select the desired steel uprights using the [Select Upright] button on the right, and check the capacity section to verify it works.

Once the upright has been verified, the next step is to then design the concrete sleepers. However, before moving on to the Concrete Member Design, open the [Calculations] tab at the bottom of the Sleeper Walls module, and make note of the loads and moment for the bottom layer sleeper, as seen below. Note that if the width of the intended concrete sleeper does not match up to the spacing of the layers in the [Calculations] tab, the sleeper size in the in the Sleeper Walls module will need to be adjusted accordingly using the [Select Sleeper] button (this is purely to get the correct loading distribution).

	Layer - ha	Sleepers	Ka.s	Ka.γs.ha	Total	wdl	wll	w*	M*	øMrd	Ratio	Def dl	Def(dl+ψl.ll)	Strength	Layer - ht
	mm		kPa	kPa	kPa	kN/m	kN/m	kN/m	kNm	kNm	M*/øM	mm	mm	Ratio/Φn	mm
	0		0.00	0.00	0.00										0
1	100	1	1.75	0.63	2.38	0.13	0.35	0.68	0.12	1.73	0.07	0.1	0.4	OK (0.07)	100
	200		1.75	1.26	3.01										200
2	300	1	1.75	1.89	3.65	0.38	0.35	1.00	0.18	1.73	0.10	0.3	0.6	OK (0.10)	300
	400		1.75	2.52	4.28										400
3	500	1	1.75	3.15	4.91	0.63	0.35	1.31	0.24	1.73	0.14	0.5	0.8	OK (0.14)	500
	600		1.75	3.79	5.54										600
4	700	1	1.75	4.42	6.17	0.88	0.35	1.63	0.29	1.73	0.17	0.7	1.0	OK (0.17)	700
	800		1.75	5.05	6.80										800
5	900	1	1.75	5.68	7.43	1.14	0.35	1.95	0.35	1.73	0.20	0.9	1.2	OK (0.20)	900
	1000		1.75	6.31	8.06			1 1		1					1000
6	1100	1	1.75	6.94	8.69	1.39	0.35	2.26	0.41	1.73	0.24	1.1	1.4	OK (0.24)	1100
	1200		1.75	7.57	9.32			•		•					1200




Using Concrete Member Design


With the loading distribution found from the Sleeper Walls module, the concrete sleeper can be designed. The first step is to input the geometry of the concrete sleeper, as shown below. Usually the concrete strength and reinforcement information is provided by the sleeper wall manufacturer.



Next the reinforcement needs to be specified. In this case, only the bottom reinforcement is needed, so the bar size of the top reinforcement is put as zero. The recommended "Bottom cover to ligs" can be found to the bottom right under "Top Steel" – refer image below. In this case, 23.0mm was used.




Refer to the [Preview] tab to check that the geometry appears correct, as shown below.





Once the geometry and reinforcement has been set, click on the [Analysis] button to the right, which will open up a linked Analysis document. In this document, input the span and load values taken from the Sleeper Walls module (the span will be the pier spacing). In addition, set the "Live Load type" to Permanent, turn the self-weight off, and set the "Dead load factor (DLF)" to 1.25 (Refer AS4678 Clause 4.1 (a) (iii)) unless input as otherwise in the Sleeper Walls module. If done correctly, the maximum moment should equal that from the Sleeper Walls module, in this case it was 0.41kNm.



Combinations:					
	Ultimate =	1.25*G+1.50*Q			
	Dead load factor (DLF) =	1.25			
Dead	1.35				
Dead	0.90				
	1.50				
	Wind load factor (WLF) =	1.00			







With the correct loads set, switch back to the design document, and click the [Max M+*] button, which will transfer the maximum positive moment from the linked Analysis. From here check that the specific limit states are met, as seen below.

It should be noted that bars specified by manufacterers generally result in an overdesigned concrete sleeper. This may result in the ku > 0.36 (i.e. non-ductile) (refer AS3600 Clause 8.1.5). To prove that the design still works, a smaller bar size can be selected such that the capacity is reached while ku < 0.36.

Section: (Concrete Member CB01) 80mm (D) x 200mm (W) beam, f'c=40MPa

Reinf't: 2-N10 bottom, ku = 0.36

 Strength:
 (+ve M) M* = 0.4kNm < øMuo = 2.3kNm</th>
 OK (0.18)

 Cracking:
 fscr = 57MPa < Fscr = 265MPa & fscr1 = 57MPa < Fscr1 = 400MPa, crack width = 0.1mm</td>
 OK (0.14,0.22)

 Ast.min:
 Ast.min = 49mm² < Ast = 157mm² (Minimum of Deemed and actual)</td>
 OK (0.31)

Interior environment with Ecsd.b*=800x10-6, Ecs*=730x10-6

If not, readjust to work as with any other design. In addition to this, the deflection will also need to be checked by clicking on the [Defl] tab at the bottom of the document. On this tab ensure the [Max Deflection] and [Transfer Reinf't] buttons have been clicked.

Once all checks have been completed, the design is finished.

